

Speaker:
Alexander Rodack

Application and Enhancement of the dOTF

2/13/2015



Outline




- A Brief Review of the dOTF
- Adaptive Optics Self-Calibration
- Using Deconvolution to Improve Results

The dOTF



The dOTF

- Induced change in pupil mask – change in pupil field – change in OTF: 'differential' OTF




- J. L. Codona, "Differential optical transfer function wavefront sensing", Opt. Eng., **52**(9), 2013.

dOTF Wavefront Sensing



- The dOTF gives a measurement of the complex field in the pupil as seen by the Science Camera
- Wavefront sensor in non-photon limited systems
 - Calibration
 - Shop Testing

dOTF Example



The dOTF examining the MMT Pupil with a Kolmogorov Phase Screen

Adaptive Optics Self-Calibration



Adaptive Optics Self - Calibration



- PSF Self-Calibration
 - Closed-loop servo uses dOTF measurements to update DM actuation
 - “Flattens” DM
 - Corrects for non-common-path aberrations
- Intentional addition of defocus

Methods for AO Self-Calibration




- Poke an edge actuator for a pupil modification
- Take 2 (or 3) pictures and compute the dOTF
- Mask off overlap region
- Read out displacements and slopes at segment/actuator positions directly from the phase measurements of the dOTF
- Replace directly measured phase with Reconstructor Matrix


Numerical Simulation Result




a)




b)




c)



d)



e)



- a) DM Shape Calculated w/ dOTF
- b) Corrected PSF
- c) Strehl Ratio over time (corrected)
- d) Uncorrected PSF
- e) Strehl Ratio over time (uncorrected)

Using Deconvolution to Enhance the Loop



Deconvolution




- The dOTF field can be blurred:
 - Area – caused by the pupil modification
 - Radial – caused by the bandwidth
- We will focus on correcting the Area blurring
 - Algorithms in development for both

Area Deconvolution



- Method for Area Deconvolution:
 - Mask overlapping parts of the dOTF
 - Fourier Transform back into image space
 - Construct a Wiener filter to recover higher-resolution measurement





dOTF blurred by pupil blocker size



Initial Simulation



Simulation done using SVD to recover high-resolution information.
Test 2 done with a higher number of modes included

Simulated
Complex
Pupil
Field



Optical
Transfer
Function
(OTF)

Deconvolution
Test 1



Deconvolution
Test 2

Next Steps



- Verify self-calibration on the testbed
 - Different bandwidths
 - Varying amounts of collected photons
- Reconstructor Matrix
- Explore Deconvolution algorithms/techniques
- Apply Deconvolution to the Self-Calibration loop
 - Once this is done, further experiments can be done with a higher degree of accuracy